

salton® *Elite* COLLECTION

INSTRUCTIONS AND WARRANTY



MODEL NO.

SECM 002

SALTON ELITE 10 CUP COFFEE MAKER

Thank you for purchasing the Salton Elite Coffee Maker. All Salton products are manufactured to set quality standards for safety and reliability and to ensure your satisfaction.

1. IMPORTANT SAFEGUARDS


When using electrical appliances, basic safety precautions should always be followed:

1. Read all instruction and save them for future reference.
2. Before connecting the appliance, please check that the voltage indicated on the appliance corresponds with the mains voltage in your home.
3. Do not touch hot surfaces. Use handles or knobs.
4. To protect against electrical hazards, never immerse cord, plugs or the appliance in water or any other liquid
5. Do not pour water in to the water tank once the appliance has been turned on.
6. Close supervision is necessary when any appliance is used by or near children or invalid persons.
7. Unplug the unit from the outlet when not in use and before cleaning. Allow the unit to cool sufficiently before cleaning or storage.
8. If any problems occur while making coffee or before cleaning the appliance, switch off the unit and unplug from the mains socket. Return the unit to an Amalgamated Appliance authorized service agent or center for examination and/or repair.
9. Do not operate the appliance with a damaged cord or plug or after the appliance has malfunctioned in any manner. Return the appliance to the nearest Amalgamated Appliances authorized service center for examination and/or repair.
10. Do not use this appliance outdoors.
11. Do not let cord hang over a counter top or table edge or place near any hot surface.
12. Do not place on or near a hot gas or electric burner or in a heated oven. Never place a hot carafe on a wet or cold surface. Do not heat in a microwave oven.
13. This appliance is intended for Household Use Only. Do not use appliance for anything other than its intended use.
14. Never leave the unit unattended while in use.
15. To fill the water tank use fresh, cold water only. If the water in your area is particularly hard, use de-stilled/filtered water in your appliance.

WARNING: The heating plate is hot when in operation. Do not touch the surface as this may result in severe burns!

2. PARTS DESCRIPTION

1. Top Cover
2. Water Tank Cover
3. Water Tank
4. Funnel-out
5. Body
6. Base
7. Power Switch
8. Glass Jug
9. Glass Jug Cover
10. Glass Jug Handle.



3. OPERATING INSTRUCTIONS

Before first use

For a perfect taste, carry out 2 or 3 boil-processes with fresh water only i.e. without coffee:

1. Once all the water has passed through the permanent filter switch off the appliance and let it cool down for about 5 minutes. Then repeat the process with fresh, cold water.

Making coffee

1. Take the water tank out and fill with cold fresh water then set it back in place.
2. Make sure the nose of the water tank base inserts securely into the groove on the unit, and allow it to slide in completely to ensure that it does not come loose when water is poured in. The number of cups can be read on the water level indicator.
3. Fill in the desired quantity of ground coffee either directly into the permanent filter or into filter paper, size “1x4” that has been fitted into the filter holder. In the latter instance, remove the permanent filter and replace with the filter paper. Do not use both the permanent filter and filter paper together.
4. Switch on the appliance. Wait until the brewing process is finished and the filter has run empty.

For large cups: takes 5-6g of ground coffee each cup.

Making more coffee straight away?

If you have made one jug of coffee and wish to make some more straight away, please switch off the coffee maker and allow at least 5 minutes for it to cool down. Then you can refill the water tank.

Cleaning

1. Always remove the mains plug from the wall socket before cleaning the appliance.
2. Never immerse the appliance completely in water.
3. Wipe the appliance down using a clean, damp cloth.
4. The glass jug, permanent filter and the filter holder can be washed in hot soapy water. Rinse with clean hot water and dry. These items can also be cleaned in a dishwasher.

5. De-scaling

1. De-scale your coffee maker regularly.
2. Operate the appliance as described above, however, use ordinary vinegar to fill the water tank and do not fill the filter with ground coffee.
3. After de-scaling let the appliance run twice more with only water to rinse away the vinegar and scale remainders.

4. SERVICE

There are no user/self serviceable parts on this product. If service becomes necessary within the warranty period the appliance should be returned to an approved Amalgamated Appliances (Pty) Ltd service centre. Servicing outside the warranty period is still available but this will be chargeable

Hints before returning the appliance for a service/repairs:

1. Has the plug been wired correctly and are the wires tight under their screws?
2. Is your household socket working properly?


Sending the appliance in for repairs:

1. Pack the appliance carefully back into its original packaging.
2. Attach your proof of purchase to the product/box.
3. Make sure that your name; contact details as well as an explanation of what is wrong/faulty with the product accompany the appliance to the Service Centre or Agent to facilitate the repairs.

WARNING: THIS APPLIANCE MUST BE EARTHED

Always ensure that the three-pin plug is connected as follows:

WARNING: THIS APPLIANCE MUST BE EARTHED
(Always ensure the three-pin plug is connected as follows :)



**PLEASE AFFIX YOUR PROOF OF PURCHASE/RECEIPT HERE
IN THE EVENT OF A CLAIM UNDER WARRANTY THIS RECEIPT MUST BE
PRODUCED.**

WARRANTY

1. Tedelex Trading (Pty) Limited ("Tedelex") warrants to the original purchaser of this product ("the customer") that this product will be free of defects in quality and workmanship which under normal personal, family or household use and purpose may manifest within a period of 1 (one) year from the date of purchase ("warranty period").
2. Where the customer has purchased a product and it breaks, is defective or does not work properly for the intended purpose, the customer must notify the supplier from whom the customer bought the product ("the supplier") thereof within the warranty period. Any claim in terms of this warranty must be supported by a proof of purchase. If proof of purchase is not available, then repair, and/or service charges may be payable by the customer to the supplier.
3. The faulty product must be taken to the supplier's service centre to exercise the warranty.
4. The supplier will refund, repair or exchange the product in terms of this warranty subject to legislative requirements. This warranty shall be valid only where the customer has not broken the product himself, or used the product for something that it is not supposed to be used for. The warranty does not include and will not be construed to cover products damaged as a result of disaster, misuse, tamper, abuse or any unauthorised modification or repair of the product.
5. This warranty will extend only to the product provided at the date of the purchase and not to any expendables attached or installed by the customer.
6. If the customer requests that the supplier repairs the product and the product breaks or fails to work properly within 3 (three) months of the repair and not as a result of misuse, tampering or modification by or on behalf of the customer, then the supplier may replace the product or pay a refund to the customer.
7. The customer may be responsible for certain costs where products returned are not in the original packaging, or if the packaging is damaged. This will be deducted from any refund paid to the customer.

TEDELEX TRADING (PTY) LTD (JOHANNESBURG)

JOHANNESBURG
CAPE TOWN
DURBAN

TEL NO. (011) 490-9000
TEL NO. (021) 552-5161
TEL NO. (031) 792-6000

www.amap.co.za